

SpeedyBee®

Quick Start Manual



Speedybee APP



Installation guide




Facebook QR Code

1

Part 1. Package



Propeller Protection Duct



2.5mm Carbon Fiber



Lipo Battery Strap



1mm FC Protection Board



x1

14mm 3D Base Mount



x1

Analog Antenna TPU Mount & Ring



x1

Analog VTX TPU Mount

Flex25 TPU Accessories (HD Version)



x5

M2 - 18mm



x1

RunCam Link TPU top Mount & Ring



x1


RunCam Link TPU Bottom Mount


Note: The accessories enclosed in the two black rectangles above will be shipped according to the corresponding version(HD/Analog)

2



Part 2. Drone Structure Explanation






5

Part 3. Screw Installation

Analog Version



C M2 - 14mm*10pcs





E M2 - 7mm*10pcs

D M2 - 12mm*8pcs

F M2.5 - 6mm*8pcs


G M2.5 - 16mm*8pcs

7



6

Analog Version




I M2 x1.53mm(Height)
Press Nuts

H M2 - 12mm*5pcs

8

HD Version



C M2 - 14mm*10pcs

E M2 - 7mm*10pcs

D M2 - 12mm*8pcs


F M2.5 - 6mm*8pcs

H M2 - 12mm*5pcs

A M2 - 18mm*5pcs

9

HD Version



I M2 x1.53mm(Height)
Press Nuts

G M2.5 - 16mm*8pcs



Scan the QR code to get the installation guide.
We recommend you scan it through the SpeedyBee App
for detailed instructions.


请扫描二维码获取安装指南
建议您通过 SpeedyBee App 扫描以获取更详细的安装指南

1

一、包装清单



圈圈



2.5mm机身



电池绑带 (18mm)



1mm飞控保护



x1

14mm机头座



x1

模拟天线座 + 圆环



x1

tx800+2p打印件

模拟版配件

高清版配件



x5

m2自攻螺丝 (18mm)



x1

RunCam Link座 + 圆环



x1

RunCam Link底座+2p


提示：方框内配件跟随版本配送

2




3

二、飞机各部件标注图



4



三、螺丝安装说明

模拟版



C m2内六角螺丝 (14mm)

E m2内六角螺丝 (7mm)


D m2内六角螺丝 (12mm)

F m2.5内六角螺丝(6mm)

G m2.5内六角螺丝 (16mm)

7

模拟版



I m2压铆螺母(2_1mm)

H m2自攻螺丝(12mm)

8

高清版



C m2内六角螺丝 (14mm)

E m2内六角螺丝 (7mm)

D m2内六角螺丝 (12mm)


F m2.5内六角螺丝(6mm)

H m2自攻螺丝(12mm)

A m2自攻螺丝(18mm)

9

高清版



I m2压铆螺母(2_1mm)

G m2.5内六角螺丝 (16mm)